



...connecting your business

LANCOM 1781A

Hardware Quick Reference



Please observe the following when setting up the device

- For devices to be operated on the desktop, please attach the adhesive rubber footpads
- Do not rest any objects on top of the device





- Keep the ventilation slots on the side of the device clear of obstruction
- In case of wall mounting, use the drilling template as supplied




- Rack installation with the optional LANCOM Rack Mount (not supplied)



LANCOM
Systems



1 Power cable
When connecting the cable to the device, turn the bayonet connector 90° clockwise until it clicks into place.



Use only the supplied power adapter.

2 LAN cable
Use the cable with the kiwi-colored connectors to connect one of the interfaces ETH1 to ETH4 to your PC or a LAN switch.

3 Optional: Serial configuration cable
You can connect the device to a PC with a configuration cable (available separately).


4 Optional: USB cable
Connect a USB storage device or a USB printer to the USB interface.

5 ISDN cable
Use the ISDN cable with the light-blue connectors to connect the ISDN interface to the NTBA if you wish to use ISDN additionally.

6 ADSL cable*
Connect the cable with the dark-blue connectors to the DSL splitter from your provider. Please ensure that you carefully follow any instructions from your provider regarding the installation of the DSL splitter and NTBA (if applicable).

*For operation without splitter please use the DSL cable supplied by your Internet provider or the enclosed adapter. For further information please contact your Internet

SETTING UP AND CONNECTING THE DEVICE



Hardware	
Power supply	12 V DC, external power adapter (230 V) with bayonet connector to secure against disconnection
Power consumption	Max. ca.10 W
Environment	Temperature range 5–40 °C; humidity 0–95 %, non-condensing
Housing	Robust synthetic housing, rear connectors, ready for wall mounting, Kensington lock; measures 210 x 45 x 140 mm (W x H x D)
Number of fans	None; fanless design, no rotating parts, high MTBF
Interfaces	

ADSL	<ul style="list-style-type: none"> Compliant to: ADSL2+ as per ITU G.992.5 Annex A/Annex B/Annex J/Annex M, ADSL2 as per ITU G.992.3 Annex A/Annex B/Annex J/Annex M, ADSL as per ITU.G.992.1 Annex A/Annex B Supports one virtual ATM circuit (VPI, VCI pair) at a time
ETH	4 individual 10/100/1000 Mbps Gigabit Ethernet ports in switch-mode by default; up to three can be configured as additional WAN ports. Ethernet ports can be electrically disabled within LCOS configuration
USB	USB 2.0 Hi-Speed host port for connecting USB printers (USB print server), serial devices (COMport servers), USB data media (FAT file system), or supported UMTS USB modems
ISDN	ISDN S ₀ bus (BRI)
Config (Com)	Serial configuration interface / COM port (8-pin Mini-DIN): 9,600–115,000 baud, suitable for optional connection of analog/GPRS modems. Supports internal COM-port server and transparent asynchronous serial-data transfer via TCP.

WAN protocols	
ADSL, Ethernet	PPPoE, Multi-PPPoE, ML-PPP, PPTP (PAC or PNS) and IPoE (with or without DHCP), RIP-1, RIP-2, VLAN
ISDN	1TR6, DSS1 (Euro ISDN), PPP, X75, HDLC, ML-PPP, V.110/GSM/HSCSD

Declaration of conformity
For the declaration of conformity, see the product page on our website www.lancom-systems.eu

Package content	
Manual	Hardware Quick Reference (DE/EN) Installation Guide (DE/EN/FR/ES/IT/PT/NL)
CD/DVD	CD/DVD with management software (LANconfig, LANmonitor, LANCAPI) and LCOS documentation
Cable	1 Ethernet cable, 3m (light-green connectors)
Cable	1 ADSL cable, 3m (light-blue connectors)
Cable	1 ISDN cable, 3m (dark-blue connectors)
Adapter	All-IP adapter (only in the EU version)
Power adapter	External power adapter (230 V), NEST 12 V/1.5 A DC/S, coaxial power connector 2.1/5.5 mm bayonet, LANCOM item no. 110723 (EU), LANCOM item no 110829 (UK)

Specific device properties are not available to LANCOM CC devices operating in CC mode according to the "Operational User Guidance".

This product contains separate modem firmware with open-source software components. These are subject to their own licenses, in particular the General Public License (GPL). The license text for the modem firmware is available on the data medium supplied. If the respective license demands, the source files for the corresponding software components will be made available on a download server upon request. License information for the device firmware (LCOS) is available in the file LCOS-Licenses.txt on the data medium supplied.

LANCOM, LANCOM Systems and LCOS are registered trademarks. All other names or descriptions used may be trademarks or registered trademarks of their owners. Subject to change without notice. No liability for technical errors and/or omissions: 110862/0614

TECHNICAL DATA