



LANCOM R&S®UF-260

Quick Reference Guide



- ① **Power button**
Press the power button to start up the device
- ② **Reset button**
Press the reset button to perform a device restart.
- ③ **Power connector**
After connecting the power supply cable to the device, turn the screwcap clockwise to prevent the jack from accidental unplugging. Use only the supplied power adapter.
- ④ **Serial configuration interface RJ45 (CONSOLE)**
Maintenance interface for expert configuration
- ⑤ **USB 3.0 interfaces**
Interfaces for reinstallation of the device software



- ⑥ **SFP interface WAN 0**
Connect the WAN 0 SFP interface to other network components via a suitable SFP module. This interface is recommended for Internet access via fiber optics. Please refer to the corresponding product supplement for instructions on initial commissioning.
- ⑦ **TP Ethernet interface WAN 1**
Connect the WAN 1 TP Ethernet interface to other network components. This interface is recommended for Internet access via copper cable. Please refer to the corresponding product supplement for instructions on initial commissioning.
- ⑧ **TP Ethernet interfaces LAN 2 - LAN 4**
Connect the LAN 2 - LAN 4 TP Ethernet interfaces with the enclosed Ethernet cable to other networking components. Please refer to the corresponding product supplement for instructions on initial commissioning.




Please observe the following when setting up the device

- > The mains plug of the device must be freely accessible.
- > For devices to be operated on the desktop, please attach the adhesive rubber footpads.
- > Do not rest any objects on top of the device and do not stack multiple devices.
- > Keep all ventilation slots of the device clear of obstruction.

Before initial startup, please make sure to take notice of the information regarding the intended use in the enclosed installation guide!
Operate the device only with a professionally installed power supply at a nearby power socket that is freely accessible at all times.

MOUNTING AND CONNECTING THE DEVICE



① **LEDs LAN 4 - WAN 0 - TP Ethernet**

Upper LEDs - link speed

Off	Link speed 10 Mbps
Orange, permanently	Link speed 1000 Mbps
Green, permanently	Link speed 100 Mbps

Lower LEDs - link activity

Off	No link detected
Orange, permanently	Link detected, no port activity
Orange, blinking	Link detected, port activity

② **LEDs POWER / DISK**

POWER off	Device switched off
POWER green	Device ready and accessible
DISK off	no HDD detected
DISK green	HDD detected

③ **LEDs WAN 1 - LAN 4 - TP Ethernet (rear panel)**

LEDs left - Link activity

Off	No link detected
Orange, permanently	Link detected, no port activity
Orange, blinking	Link detected, port activity

LEDs right - link speed

Off	Link speed 10 Mbps
Orange, permanently	Link speed 1000 Mbps
Green, permanently	Link speed 100 Mbps

Hardware	
Power supply	12 V DC, external power supply
Power consumption	30 W max.
Environment	Temperature range 0–40 °C; humidity 5–90 %; non-condensing
Housing	Robust metal housing, network connectors on the front
Fan	1
Dimensions (mm)	231 x 44 x 200 (W x H x D)
Interfaces	
ETH	4x 10 / 100 / 1000 Mbps Gigabit Ethernet ports
SFP	1x 1 Gbps SFP port
USB	2x USB 3.0 ports
Console	1x RJ45 configuration interface
Declaration of conformity	
Hereby, LANCOM Systems GmbH Adenauerstrasse 20/B2 D-52146 Wuerselen, declares that this device is in compliance with Directives 2014/30/EU, 2014/35/EU, and 2011/65/EU. The full text of the EU declaration of conformity is available at the following internet address: www.lancom-systems.com/ce/	
Package content	
Documentation	Quick Reference Guide (DE/EN), Quick Install Guide (DE/EN), Service & Support Guide (DE/EN)
Accessories	1 Ethernet cable, 1 power supply unit with IEC power cable, 1 set adhesive rubber pads