



## Hardware Quick Reference

# LANCOM 1926VAG-5G



①

### 5G antenna connectors

Connect the supplied cellular antennas to the connectors MAIN / AUX or MIMO1 / MIMO2 at the front of the device.



②

### G.FAST / VDSL / ADSL interfaces\*

If required, use the supplied DSL cables for the IP-based line to connect each G.FAST / VDSL / ADSL interface to a separate provider's telephone socket. For more information, please contact your Internet service provider.

\* Please use the appropriate cables depending on the design




③

### WAN 1 interfaces (SFP / TP combo port)

Insert a suitable SFP module (e.g. 1000Base-SX or 1000Base-LX) into the SFP port. Choose a cable compatible with the SFP module and connect it as described in the module's documentation. SFP module and cable are not included.

If desired, alternatively connect the WAN 1 TP interface to a WAN modem using an ethernet cable.



④

### WAN 2 interface (TP)

Connect the WAN 2 interface to a WAN modem using an Ethernet cable.



⑤

### Ethernet interfaces

Use the cable with the kiwi-colored connectors to connect one of the interfaces ETH 1 to ETH 4 to your PC or a LAN switch.



⑥

### Analog interfaces

Connect analog terminal devices to the analog interfaces either directly via RJ11 or with the help of the enclosed TAE adapters.




⑦

### ISDN interfaces

ISDN 1: Internal (NT) ISDN bus  
ISDN 2: Internal (NT) ISDN-bus

A 100-Ohm resistor for line termination is switchable in LCOS.



⑧

### SIM card slot

Slide the SIM card into the SIM card slot using the marker to ensure that the card is the right way round. Ensure that the SIM card clicks into place on insertion. To remove the card from the device, press the card lightly into the device. Let go to release the SIM card from the slot.



⑨

### Configuration interface


Use the included serial configuration cable to connect the serial interface (COM) to the serial interface of the device you want to use for configuring / monitoring.



⑩

### USB interface

You can use the USB interface to connect a USB printer or a USB storage device.



⑪

### Power connector and grounding point (device back side)

Supply power to the device via the power connector. Please use the IEC power cable supplied (separately available for WW devices).



⑫

**ATTENTION:** High touch current possible! Connect to earth before connecting the power supply.

Before initial startup, please make sure to take notice of the information regarding the intended use in the enclosed installation guide!

Operate the device only with a professionally installed power supply at a nearby power socket that is freely accessible at all times.

The power plug of the device must be freely accessible.

Please note that support for third-party accessories is not provided.





### Please observe the following when setting up the device

- For devices to be operated on the desktop, please attach the adhesive rubber footpads
- Do not rest any objects on top of the device and do not stack multiple devices
- Keep all ventilation slots of the device clear of obstruction
- Mount the device into a 19" unit in a server cabinet using the provided screws and mounting brackets. Pay attention to the "R" and "L" marks on the brackets for accurate mounting.

# Hardware Quick Reference

## LANCOM 1926VAG-5G



A	B	C	D	E	F
5G / VoIP / VPN / POWER	RESET	G.FAST / VDSL 1 / VDSL 2	WAN 1 / WAN 2	ETH 1 - ETH 4	ISDN 1 (NT) / ISDN 2 (NT)
<b>5G</b>	Reset button	Off	Green, orange off	Green, orange off	Off
Off	Short press > Restart the device Long press > Reset the device	Interface deactivated	No networking device connected	No networking device connected	Interface deactivated
Green, permanently		DSL connecting	Connection to network device operational, no data traffic	Connection to network device operational, no data traffic	D-channel active
Green, flickering		DSL connection active	Data transmission	Data transmission	ISDN connection active
Orange, permanently		DSL data transmission	1000 Mbps	1000 Mbps	ISDN connecting
Orange, blinking		DSL transmission error	10 / 100 Mbps	10 / 100 Mbps	ISDN hardware error
Red, permanently		DSL hardware error			ISDN hardware error
Red / green, blinking		DSL training			blinking synchronously
Red / orange, blinking		DSL sync			Connection inactive
Uploading module firmware					
<b>VoIP</b>					
Off					
Green, permanently					
Red, permanently					
Red or green, inverse flashing					
<b>VPN</b>					
Off					
Green, permanently					
Green, flashing					
<b>POWER</b>					
Off					
Green, permanently*					
Green / red, blinking					
Red, blinking					
1x green inverse blinking*					
2x green inverse blinking*					
3x green inverse blinking*					

Power supply	Internal power supply unit (100–240 V, 50-60 Hz)
Power consumption	Max. 38 W
Environment	Temperature range 0–40 °C, humidity 0–95 %; non-condensing
Housing	Robust metal housing, 1 HU with mounting brackets for 19" installation, W 345 x H 44 x D 253 mm)
Number of fans	1 quiet fan

<b>Interfaces</b>	
G.FAST / VDSL 1 / VDSL2	
WAN 1 / WAN 2	
ETH 1 - ETH 4	
Analog 1 - Analog 4	Detailed interface specifications can be found in the device data sheet after entering the device name at <a href="http://www.lancom-systems.com/downloads">www.lancom-systems.com/downloads</a> .
ISDN 1 / ISDN 2	
Config (COM) / V.24	
USB	
5G	

<b>Data transmission in cellular networks - supported standards and power (dBm)</b>	
LTE / LTE Advanced	Band 1: 24.0; band 3: 24.8; band 7: 24.8; band 8: 24.0; band 20: 24.0; band 34: 24.0; band 38: 24.8; band 40: 24.8; band 42: 24.8
5G NR	n1: 24.0; n3: 24.0; n28: 24.0; n41: 24.0; n77: 24.5; n78: 24.5

<b>Package content</b>	
Cables	2x DSL cables for IP-based connection, 4.25 m, or 2x DSL cables, 3 m (dark blue connectors), depending on the version; 1x Ethernet cable, 3 m (kiwi colored connectors); 1 IEC power cord 230 V (not for WW devices)
Antennas	4x 5G/4G antennas for 5G/LTE
Adapters	4x TAE adapters (RJ11 - TAE)
Mounting brackets	2x 19" brackets for rack mounting

\*) The additional power LED statuses are displayed in 5-seconds rotation if the device is configured to be managed by the LANCOM Management Cloud.

This product contains separate open-source software components which are subject to their own licenses, in particular the General Public License (GPL). The license information for the device firmware (LCOS) is available on the device's WEBconfig interface under "Extras > License information". If the respective license demands, the source files for the corresponding software components will be made available on a download server upon request.

Hereby, LANCOM Systems GmbH | Adenauerstrasse 20/B2 | D-52146 Wuersele, declares that this device is in compliance with Directives 2014/30/EU, 2014/53/EU, 2014/35/EU, 2011/65/EU, and Regulation (EC) No. 1907/2006. The full text of the EU Declaration of Conformity is available at the following Internet address: [www.lancom-systems.com/doc](http://www.lancom-systems.com/doc)