
please use the LANCOM Switch Rack Mount L250, item no.: 61432, which is available as an

1 IEC power cord, 1 serial configuration cable 1.5 m

Hardware Quick Reference LANCOM GS-3652XP





3 TP Ethernet interfaces 100M / 1G / 2.5G PoE+

or a LAN switch.

LANCOM GS-3652XP

Connect the configuration interface via the included serial configuration cable to the serial interface of the device you want to use for configuring / monitoring the switch.



TP Ethernet interfaces 10M / 100M / 1G PoE+ Use Ethernet cables to connect the interfaces 1 to 36 to your PC or a LAN switch.

Use Ethernet cables to connect the interfaces 37 to 48 to your PC












Insert suitable LANCOM SFP modules into the SFP+ interfaces 49 to 52. Choose cables which are compatible with the SFP modules and connect them as described in the module's documentation.









SFP+ interfaces 1G / 10G



Supply power to the device via the power connector. Please use the IEC power cable supplied or a country-specific LANCOM Power Cord.





4 TP Ethernet ports 100M / 1G / 2.5G PoE+

Device powered off Device operational Hardware error Port LEDs show link / activity / port speed status Port LEDs show PoE status

Mode/Reset button

System: off

Link/Act/Speed:

Short press	Switching the port LED display
~5 sec. pressed	Device restart
Pressed until all port	Configuration reset and device restart
LEDs glow	

TP Ethernet ports 10M / 100M / 1G PoE+

System / Link/Act/Speed / PoE LED

LEDs switched to Link/Act/Speed mode	
Off	Port inactive or disabled
Green	Link 1000 Mbps
Green, blinking	Data transfer, link 1000 Mbps
Orange	Link < 1000 Mbps
Orange, blinking	Data transfer, link < 1000 Mbps

I FDs switched to PoF mode

LEDS SWITCHED TO POE MODE		
Off	f Port inactive or disabled	
Green	Port enabled, power supply to connected device	
Orange	Hardware error	

 LEDs switched to Link/Act/Speed mode	
 Off	Port inactive or disabled
 Green	Link 2500 - 1000 Mbps
Green, blinking	Data transfer, link 2500 - 1000 Mbp
 Orange	Link < 1000 Mbps
 Orange, blinking	Data transfer, link < 1000 Mbps

Off	Port inactive or disabled
Green	Port enabled, power supply to
	connected device
Orange	Hardware error

 Off	Port inactive or disabled
Blue	Link 10 Gbps
 Blue, blinking	Data transfer, link 10 Gb
 Green	Link 1 Gbps
 Green, blinking	Data transfer, link 1 Gbp

Hardware

Number of fans

Package Content

Cables

	LEDs switched to Link/Act/Speed mode		
	Off	Port inactive or disabled	
	Green	Link 2500 - 1000 Mbps	
	Green, blinking	Data transfer, link 2500 - 1000 Mbps	
	Orange	Link < 1000 Mbps	
_	Orange blinking	Data transfer link < 1000 Mbns	

	or or i porto roy roo	
_	Off	Port inactive or disabled
	Blue	Link 10 Gbps
	Blue, blinking	Data transfer, link 10 Gbps
	Green	Link 1 Gbps
••••	Croop blinking	Data transfer link 1 Chas

 LEDs switched to Link/Act/Speed mode	
 Off	Port inactive or disabled
 Green	Link 2500 - 1000 Mbps
Green, blinking	Data transfer, link 2500 - 1000 Mb
 Orange	Link < 1000 Mbps
 Orange, blinking	Data transfer, link < 1000 Mbps


LEDs switched to PoE mode

	011	Death to a setting an alternative of
	5 SFP+ ports 1G / 10G	
	Orange	Hardware error
t	Green	connected device









Operate the device only with a professionally installed power supply at a nearby power socket that is freely accessible at all times.

The power plug of the device must be freely accessible.

Please note that support for third-party accessories (SFP and DAC) is not



Please observe the following when setting up the device

- → For devices to be operated on the desktop, please attach the adhesive rubber footpads
- → Do not rest any objects on top of the device
- → Keep all ventilation slots on the side of the device clear of obstruction
- → Mount the device into a 19" unit in a server cabinet using the provided screws and mounting brackets. If an additional rear support surface is required for more stable mounting of the switch, please use the LANCOM Switch Rack Mount L250, which is available as an accessory.