




Hardware Quick Reference LANCOM GS-1108P



①

① **TP Ethernet ports**
Connect one of the TP Ethernet ports 1-8 via an Ethernet cable to your end device or another LAN switch.



② **Power connector (back side of the device)**
Supply power to the device via the power connector on the back. Please use the supplied IEC power cable.




Before initial startup, please make sure to take notice of the information regarding the intended use in the enclosed installation guide!

Operate the device only with a professionally installed power supply at a nearby power socket that is freely accessible at all times.

Please observe the following when setting up the device
 → The power plug of the device must be freely accessible.
 → For devices to be operated on the desktop, please attach the adhesive rubber footpads
 → Do not rest any objects on top of the device
 → Keep all ventilation slots on the side of the device clear of obstruction
 → Please note that support service for third-party accessories is excluded.

Mounting & connecting



①

②

① POWER	
Off	Device switched off
Green	Device operational

② L/A / PoE	
L/A	
Green permanently	Link 1000 Mbps, no data transmission
Green flickering	Data transmission 1000 Mbps
Orange permanently	Link 10 / 100 Mbps, no data transmission
Orange flickering	Data transmission 10 / 100 Mbps
PoE	
Off	Power supply for connected device disabled
Green	Power supply for connected device enabled

Hardware	
Power supply	Internal power supply unit (110–230 V, 50–60 Hz)
Power consumption	Max. 70 watts
Environment	Temperature range 0–40 °C; humidity 10–90 %; non-condensing
Housing	Robust metal housing with screw-on 19" mounting brackets (220 × 44 × 135 mm > W x H x D), network connectors on the front
Number of fans	1 quiet fan
Interfaces	
ETH	8 TP Ethernet ports 10 / 100 / 1000 Mbps
Package content	
Cable	1 IEC power cord

Hereby, LANCOM Systems GmbH | Adenauerstrasse 20/B2 | D-52146 Wuersele, declares that this device is in compliance with Directives 2014/30/EU, 2014/35/EU, 2011/65/EU, and Regulation (EC) No. 1907/2006. The full text of the EU Declaration of Conformity is available at the following Internet address: www.lancom-systems.com/doc